



*reximex*



**LYRA**

**PCP AIRGUN OWNERS MANUAL**

.177 Cal. - .22 Cal. - .25 Cal

**READ ALL INSTRUCTIONS AND WARNINGS  
IN THIS MANUAL BEFORE USING THIS AIRGUN**

# INDEX



<u>Page</u>	<u>Content</u>
1	Warranty
1	Warning
2	Safety Review
3	General Instructions & Operating Safety
3	Manual Safety
4	Operating Instructions
4	A. Filling The Air Cylinder
5	B. Loading The Airgun
7	C. Un-Loading & Un-Chocking The Airgun
7	D. Cocking Lever Replacement
8	E. Jammed Ammo
8	F. Trigger Adjustment
9	H. Maintenance
9	Replacement Of O-Rings
9	I. Storage
10	Mechanism Part's & Part Numbers
11	Mechanism Part List

## 1. WARRANTY

All REXIMEX PCP Airguns carry a One Year Warranty against faulty workmanship and defective materials. Contact the dealer from which you purchased the airgun if it becomes necessary. If the airgun develops a defect within the warranty period, contact the dealer from whom it was purchased. The guarantee does not cover any damage caused by tampering with the airgun.

This airgun should only be disassembled by factory-authorized repairmen.

## 2. WARNING!

**WARNING!** NOT A TOY. THIS AIRGUN IS RECOMMENDED FOR ADULT USE ONLY. MISUSE OR CARELESS USE MAY CAUSE SERIOUS INJURY OR DEATH. MAY BE DANGEROUS UP TO 800 YARDS (732 METERS).

**WARNING!** DO NOT BRANDISH OR DISPLAY THIS AIRGUN IN PUBLIC. IT MAY CONFUSE PEOPLE AND MAY BE A CRIME.

DO NOT CHANGE THE COLORATION AND MARKINGS TO MAKE IT LOOK MORE LIKE A FIREARM. POLICE AND OTHERS MAY THINK IT IS A FIREARM AND IT MAY BE A CRIME.

YOU AND OTHERS NEXT TO YOU SHOULD ALWAYS WEAR SHOOTING GLASSES TO PROTECT YOUR EYES.

BUYERS AND USERS HAVE TO OBEY THE LAWS ABOUT THE USE AND OWNERSHIP OF THIS AIRGUN

**WARNING!** NEVER ATTEMPT TO DISASSEMBLE THIS AIRGUN WHILE IT IS CHARGED!  
FAILURE TO OBEY THIS INSTRUCTION COULD RESULT IN PERSONAL INJURY OR DAMAGE TO THE AIRGUN!

### 3 SAFETY REVIEW

- Never use the airgun if you are intoxicated or under the influence of drugs.
- Even if there is no pressure sign on the manometer, never disassemble the pressurized tube!
- Never fire the airgun when it is empty of air or when the air cylinder is removed!
- Never point the airgun at anyone, or allow anyone to point an airgun at you!
- Treat every airgun as if it is loaded even if you know it is not loaded!
- Always carry the airgun so that the direction of the muzzle is under control, even if you stumble.
- Always be sure of your target and what lies behind it before firing your airgun.
- Never leave a loaded airgun unattended.
- Beware of targets that tend to cause ricochets.
- It is recommended that eye protection is worn when charging the air cylinder.
- Always use caution when operating this airgun.
- Only use dry cloth to clean any dirt inside the barrel for various reasons (humidity, dust, etc.)
- In your airgun, only use synthetic or mineral base high viscosity oil in order not to create filling effect with lower tolerance parts.
- Learn and obey the laws in your location.
- Be responsible in your use of this weapon!

REXIMEX PCP airguns are designed specifically for use with DRY COMPRESSED AIR. NO OTHER GAS OR GAS COMBINATION CAN BE USED.

The Airgun may be filled by a Diving Scuba Tank or a suitable compressor  
MAXIMUM SAFE WORKING PRESSURE (SWP): 200 BAR



#### **DANGER OF EXPLOSION!**

THE AIR TANK POSES THE EXPLOSION RISK IF IT GETS HEATED SUBJECT TO SUNTRAY FOR EXTENDED PERIOD OF TIME.


(Max. + 40° / Min. -05°)

OTHERWISE, THE AIRGUN SHOULD BE LEFT TO COOL DOWN IN A COOL ENVIRONMENT  
RECOMMENDED TO BE TRANSPORTED UNDER MAXIMUM 80 BARS PRESSURE DURING FLIGHTS.



## 4 GENERAL INSTRUCTIONS & OPERATING SAFETY

- REXIMEX Airgun should be fitted with a scope or alternate optic sights before use.
- Before using your airgun, read and abide by the basic safety rules.



## MANUAL SAFETY

**CAUTION:** Like all mechanical devices, airgun safety can fail. Even when the safety is on "SAFE" you should continue to handle the airgun in a safe manner.

Locate the safety switch of the airgun directly above the trigger guard.

- 1- To set the safety ON, pull the safety switch to the rear.
- 2- To set the safety OFF, push the safety switch to the front.

### A- Airgun on "S" (SAFE) Position

To set the safety on, push the safety switch from the back side of the airgun. In this position the trigger cannot be pulled and the airgun cannot be fired.



### B- Airgun on "F" (FIRE) Position

To set the safety off, push the safety switch from the front side of the airgun. In this position the trigger can be pulled and the airgun can be fired.



**WARNING!** KEEP THE AIRGUN IN THE "SAFE" POSITION UNTIL YOU ARE READY TO SHOOT. WHEN READY PUSH THE SAFETY SWITCH TO "FIRE" POSITION

## 5. OPERATING INSTRUCTIONS

### A. FILLING THE AIR CYLINDER


#### Warning!

1. Before filling the air cylinder; make sure the airgun is on "S" (SAFE) position, no pellets are loaded in the air airgun and/or barrel and magazine is not mounted in the gun.

**NOTE:** If the air cylinder pressure is at "0" Bar, then it will be necessary to cock the airgun to remove the force of the Hammer against the firing Valve. Otherwise, the air will pass through the firing Valve out the barrel, and the air cylinder will not pressurize.

2. Take all safety measures before filling the air cylinder. It is compulsory for the user and to wear eye & ear protection when filling the air cylinder.

3. While filling in the air cylinder; the pressure in the air cylinder must be monitored from the air gauge of the hand pump or scuba charging kit, Do not look at the air gauge on the air cylinder during filling process. Instead, reference the gauge on your fill device.



Assemble the filling equipment hose with the filling probe that is provided inside the box. Pull back on the outer sleeve on the quick connect fitting to release it from your airgun, when your tube is filled. If you hear SOUND of air during the first filling, move the jack and enable the O rings to be air-proof. (if the leakage continues, O rings might be deformed)

#### Overfill

In case of overfilling, PRESSURE SAFETY VALVE WASHER is located on your airgun. This washer will tear if the air pressure on your airgun reaches to a dangerous level and this will prevent any potential over pressure danger.

In case the safety valve washer is torn, a spare washer is included in your box and it needs to be changed.

## B. LOADING THE AIRGUN

**CAUTION:** Never re-use ammunition.

Review the entire manual, including the section on Safety, before firing your airgun.

**CAUTION:** Know your airgun's loading mechanism for safest use! Pellets can either be loaded one by one using a single shot tray, or multiple pellets may be loaded using the rotary magazine. With the magazine placed correctly, EVERY action of closing the side lever WILL place a pellet into the chamber.

**DO NOT TRY TO CLOSE THE SIDE LEVER WHEN THE MAGAZINE IS NOT LOADED!!!**

Do not re-cock the airgun while there is pellet loaded inside the chamber!! This will load multiple pellets at the same time and may damage your airgun.

Removal of the magazine WILL still leave the chambered pellet in place unless the airgun is fired.

### Loading the Magazine

Make sure your airgun is on "SAFE" position and is pointed to a SAFE DIRECTION.


If the magazine is fitted on the airgun, remove it to begin loading or Unloading.

Move the clear cover over the catch point and rotate in the direction of the arrows (clockwise) Fig. A.

Place a finger under the magazine covering the hole, place the first pellet in the magazine nose first, make sure that the pellet does not protrude out of the magazine. If the pellet does protrude, simply push the pellet inward. Fig. B

Rotate the cover counterclockwise and place the remaining pellets into the magazine. Upon completion rotate the cover until it comes to rest. Fig. C

If it looks like Fig. D. The magazine is now ready for use.



## Placing the loaded Magazine on the Airgun & Firing Safety

**NOTE:** Following these directions will load your airgun and it will be ready to FIRE.

Make sure your airgun is on "SAFE" position and is pointed to a SAFE DIRECTION.

- To fit the magazine into the airgun, pull the cocking handle backwards until it stops.
- With the cover of the magazine facing the butt of the airgun, insert the magazine from the right side and push it inward until it snaps into place.
- The line on the back of the magazine should align with the line on the loading slot of the airgun. **YOU WILL DAMAGE THE MAGAZINE IF IT IS NOT PLACED CORRECTLY**
- Pull the cocking handle to its rear-most position.
- Push the cocking handle forward fully and ensure that it lays flat against the airgun in order to chamber a pellet.
- After following these steps and reading the entire manual, including the section of safety procedures, your airgun is now loaded and ready to fire.

**DO NOT CLOSE THE COCKING HANDLE / MAGAZINE RELEASE BOLT UNTIL YOU ARE READY TO FIRE.**

- Aim at your intended target and disengage the safety and prepare to shoot.
- Pull the trigger gently and the airgun will fire.
- To reload airgun, pull the cocking handle to its rear-most position. This will index the magazine and align the next pellet with the barrel. Then, repeat previous steps.



## C. UN-LOADING & UN-COCKING THE AIRGUN

### Un-loading & Removing the Magazine

1. Pulling the cocking handle to its rear-most position and Pushing it forward fully while the magazine is loaded will result in chambering a pellet.
2. To unload the airgun, it is recommended to fire the pellet in a **SAFE DIRECTION**.
3. Pull the side lever back to the rear position.

**CAUTION.** This action **WILL** cock the airgun.

4. Push the magazine out of the receiver from the left side.
5. Un-cock the airgun for safe storage.

### Un-Cocking

When you are finished shooting, remove the magazine as instructed and un-cock the airgun by following the steps below:

11. Point the airgun in a **SAFE DIRECTION**.
12. Take the airgun on "FIRE" position.
13. Pull the cocking handle back to its rear-most position.
14. While firmly holding the cocking handle in the rear position, pull the trigger.
15. Continue to hold the trigger back while sliding the side lever forward to the latched position.
16. Release the trigger.
17. Put the airgun on "SAFE" position.

**WARNING!** EVEN THOUGH YOU FOLLOW THE UNLOADING PROCEDURE, CONTINUE TO TREAT THE AIRGUN AS IT IS LOADED. NEVER POINT THE AIRGUN AT ANYTHING YOU DO NOT INTEND TO SHOOT.

## D. POWER ADJUSTMENT

Simply rotate the power switch while the airgun is un-cocked in the "+" or "-" direction and set the desired power level.



## E. JAMMED AMMO

A jammed ammo is usually caused by firing the airgun when the air pressure is too low. Please, do not operate your airgun below 100 bar (1500 PSI) air pressure.

**CAUTION:** Never try to look through the barrel to see if a jammed ammo is cleared.

Make sure the airgun is on "SAFE" position and pointed in a SAFE DIRECTION.

- Pull the cocking handle back to its rear-most position.
- Insert a clearing rod of the proper size into the barrel, starting from the muzzle (Barrel may be damaged if the clearing rod is not proper size)


**NOTE:** Cocking handle must be at its rear-most position for the jammed ammo to clear the breech when it is pushed out by the ramrod.

- Push or tap ammo towards the breech end of the barrel until the pellet is extracted from the chamber.
- Operate carefully in order not to damage the chamber sealing O-ring.
- Remove and discard the ammo.
- Do not reuse that ammo.

If you are not successful removing the jammed ammo following above instructions, take no further action. REXIMEX Technical Service or an Authorized Service Station will unjam your airgun (Free of charge during the warranty period).

## F. TRIGGER ADJUSTMENT

- First, remove the grip area using an Allen wrench. (Bottom of the grip)
- After removing the grip area successfully, trigger sensitivity adjustment may be done using an Allen wrench as shown on the picture.
- Re-mount the grip using the Allen wrench.



## H. MAINTENANCE

- Apply Reximex silicone chamber oil on the barrel breech and O-rings every 3 months or 500 shots.
- Periodically check your airgun. If anything feels different, like a shorter or weaker trigger pull, this may mean worn out or broken parts, call Reximex customer service for assistance before re-using your airgun.

## REPLACEMENT OF O-RINGS

After a period of time, the O-rings on the fill probe will need to be replaced. The need for this will become noticeable if air is heard leaking from the nozzle while charging the airgun.

## LUBRICANT

General: Keep the airgun clean and wipe it off with regular gun oil and a cloth occasionally.

Fill probe: Apply a thin layer of suitable mineral based oil occasionally or when dried out.

Magazines: Apply a thin layer of suitable mineral based oil occasionally or when dried out.

Cocking handle and Sidelever Sliding Surface: Apply a thin layer of a standard multipurpose grease occasionally or when dried out.


**WARNING:** Never use grease or spray oil in the moving parts inside the gun. This can result in unstable power and also leakage. Be moderate with lubricant.

## I. STORAGE

Store in a place that is dry and dark. Store with air pressure between 50-200 bar in the airgun.

### **WARNING!**

- Keep away from spaces with high humidity as steel parts might corrode.
- Keep away from bright sunlight as this shortens the life of the O-rings.
- Never store the airgun loaded with pellets.

**MECHANISM PARTS & NUMBERS**





## PART LIST

Part Code	Part Name	Part Code	Part Name
LYR - 1-1	Lyra Chassis	3B-002	M3x6 Socket Countersunk Head Screw (ISO-10642)
LYR - 1-2	Lyra Top Cover	1A-010	M4x8 Flat Point SetScrew (ISO-4026)
RKS - 1-14	Reximex Counter Pin	8A-003	D3 Steel Ball
RKS - 1-15	Reximex Counter Pin Spring	3A-023	M5x16 Socket Head Screw (ISO-4762)
<b>RKS - 1-21</b>	<b>Reximex Pellet Pusher *</b>	<b>R-MAG - 1-2</b>	<b>Reximex Magazine*</b>
RKS - 1-26	Reximex Pellet Pusher Screw (Hammer Carrier Screw)	2A-026	O-Ring - 16x2 NBR70
RKS - 1-19	Reximex Pellet Pusher Pin	TSG - 1-1	Reximex Hammer Valve Housing
RKS - 1-16	Reximex Cocking Lever Link	2B-026	O-Ring - 16x2 NBR90
ZN - 1-13	Zone Cocking Lever	2A-004	O-Ring - 3x1 NBR70
RKS - 1-20	Reximex Cocking Lever Link Rear Screw	RCV - 1-1	Reximex Hammer Valve
ZN - 1-25	Zone Cocking Lever Bushing	TSG - 1-2	Reximex Hammer Valve Seal
ZN - 1-24	Zone Cocking Lever Handle	TSG - 1-3	Reximex Hammer Valve Spring
RKS - 1-4	Reximex Hammer	5C-002	M5 Bonded Seal
RKS - 1-5	Reximex Hammer Spring	DC - 1-1	T2 Thin Seal
RKS - 1-6	Reximex Hammer Spring Base Housing	RB - 1-1	Air Tank Baromeer
RKS - 1-7	Reximex Hammer Spring Base Bushing	CBTA - 1-1	Air Tank Rear Tap (For Steel Tube)
RKS - 1-8	Reximex Hammer Spring Base Inner Piece	EMS - 1-1	Burst Disk Screw
RKS - 1-9	Reximex Hammer Screw	EMS - 1-2	Burst Disk
RTB - 1-1	Reximex Trigger Finger Piece Rod Base	2A-050	O-Ring - 23.39x3.53 NBR70
RTB - 1-3	Reximex Trigger Finger Piece Rod Base Spring	2A-049	O-Ring - 23x2.5 NBR70
RKS - 1-24	Trigger Finger Piece Rod	RT - 3-2	Air Tube Rear Tap Inner Lid (1.0 Thread)
RTB - 1-4	Reximex Trigger Finger Piece	CST - 1-1	Steel Tube - 425mm
RTB - 1-5	Reximex Trigger Lever	CBTF - 1-1	Air Tank Front Tap (For Steel Tube)
RTB - 1-6	Reximex Hammer Holder	5C-001	M3 Bonded Seal
RTB - 1-7	Reximex Hammer Holder Spring	TBF - 1-4	Discharge SetScrew
RTB - 1-8	Reximex Hammer Holder Sear	DJ - 0-3	Dolum Jaki Arka Kapağı
RTB - 1-9	Reximex Hammer Holder Sear Spring	DJ - 0-4	Filling Port Spring
RKS - 1-22	Reximex Side Cover	2B-005	O-Ring - 3x1.5 NBR90
APX - 2-2	Apex Safety	DJ - 0-2	Filling Port Valve
LYR - 1-4	Lyra Trigger Guard	DJ - 1-1	Filling Port
LYR - 1-3	Lyra Power Adjustment Valve	2A-022	O-Ring - 14x1.5 NBR70
LYR - 1-5	Lyra Safety Catch Spring	RN - 6-1	Reximex 8-Ring
3C-006	M4x12 Hexagon Socket Button Head Screw (ISO-7380)	2A-041	O-Ring - 21x2 NBR70
6A-001	3x7x3 Ball Bearing	TK - 1-6	Reximex Tube Cap - 6
3A-009	M4x6 Socket Head Screw (ISO-4762)	<b>2A-012</b>	<b>O-Ring - 5.5x1.5 NBR70 *</b>
3C-001	M3x8 Hexagon Socket Button Head Screw (ISO-7380)	2A-014	O-Ring - 8x1.5 NBR70
4A-025	3x20 Parallel Pin (ISO-8734)	<b>RN - 1-1</b>	<b>Reximex Barrel 58cm *</b>
4A-023	3x16 Parallel Pin (ISO-8734)	LYR - 2-1	Lyra Moderator
1A-002	M3x3 Flat Point SetScrew (ISO-4026)	3E-002	5x20 Wood Screw (DIN-7996)
4A-016	2.5x16 Parallel Pin (ISO-8734)	RTL - 1-14	Reximex Butt-Pad - 3
1A-016	M5x10 Flat Point SetScrew (ISO-4026)	RTL - 1-12	Reximex Butt-Pad Frame - 1
1A-018	M6x6 Flat Point SetScrew (ISO-4026)	LYR - 4-1	Lyra Stock
4A-028	3x25 Parallel Pin (ISO-8734)	RTL - 1-13	Reximex Short Sling Screw
2A-003	O-Ring - 3.5x1.5 NBR70	LYR - 4-2	Lyra Stock Lower Picatinny Bushing
4A-003	2x6 Parallel Pin (ISO-8734)	LYR - 4-3	Lyra Stock Lower Picatinny Bushing Screw
1E-004	M5x7 - Ball Point SetScrew	RAP - 1-5	Reximex Stock Fix Screw Bushing
1A-016	M5x10 Flat Point SetScrew (ISO-4026)	3B-023	M6x20 Socket Countersunk Head Screw (ISO-10642)






**REXIMEX İt. İh. Av Malz. Sav. San. Tic. Ltd. Şti.**

 Bayařsar Mahallesi 41958. Sokak No:3 Beyřehir / Konya

 0332 511 0055  [export@reximex.com](mailto:export@reximex.com)

 [www.reximex.com](http://www.reximex.com)

